

NOTICE DE MONTAGE

PROTECTION DE COURROIE ERMAX ADAPTABLE SUR YAMAHA 530 T MAX DX / SX 2017/2019 / 560 T MAX 2020 → ∞

Durée de montage estimée : 45mn



Kit de fixation

- 4 vis 6x15 grosses têtes noires
- 1 entretoise métallique Ø8 int. Ø14 ext. ép. 5 mm (pour le 560 T Max)

Montage

- Mettre le scooter sur la béquille centrale.
- Démontez la roue arrière.
- Démontez le boîtier situé entre les protections de courroies supérieure et inférieure d'origine (voir photo ci-dessous).
- Démontez les parties avant de la protection de courroie supérieure et inférieure.
- Démontez la partie arrière de la protection de courroie supérieure.
- Remplacer les protections de courroies d'origine par le cache courroie Ermax.
- Fixer les protections de courroies Ermax à l'aide des vis fournies dans le kit.
- Remonter la roue arrière et contrôler la tension de courroie

Vidéo de montage disponible sur la chaîne Youtube d'Ermax !



Pour le 560 T Max :
Insérer l'entretoise métallique entre le boîtier et la patte de fixation lors du remontage du boîtier

« ATTENTION »

- * Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.
- * Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.
- * En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.
- * Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.
- * Attention aux serrages excessifs qui pourraient abîmer ou casser nos accessoires en plastique et les vis en aluminium.
- * Durcir l'amortisseur arrière lors de conduites chargées ou sur routes bosselées.

FITTING INSTRUCTIONS

ERMAX BELT COVER ADAPTABLE ON YAMAHA 530 T MAX DX / SX 2017/2019 / 560 T MAX 2020 → ∞

Estimated mounting time : 45mn




Fitting kit

- 4 screws 6x15 black big head
- 1 metallic spacer Ø8 int. Ø14 ext. th. 5 mm (for the 560 T Max)

Fitting instructions

- Put the scooter on the central stand.
- Remove the rear wheel.
- Dismount the box located between the original upper and lower belt covers (see photo below).
- Dismantle the front parts of the upper and lower belt cover.
- Remove the rear part of the upper belt cover.
- Replace the original belt covers by the Ermax belt protection.
- Fit these Ermax belt covers thanks to the supplied screws.
- Refit the rear wheel and control the belt tension.

The video of the mounting can be viewed on the Ermax Youtube channel !



For the 560 T Max :
Insert the metallic spacer between
the box and the fixing bracket
while replacing the box

« CAUTION »

- * Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.
- * Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.
- * Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustments to fit.
- * The mentioned label of motorbikes's manufacturers are indicated exclusively as a reference to Ermax accessories.
- * Care to excessive clampings which may damage or break our plastic accessories and aluminium screws.
- * Harden the rear shock absorber while drivings with load or on dented roads.